

Welcome to the Luxaflex lifestyle

Thank you for purchasing Luxaflex® LumiShade® Window Coverings. With proper operation and care your new blinds will provide years of beauty and performance. Please review this instruction booklet thoroughly for operation and care information.

The information and advice included in this brochure has been prepared with care. However, we are unable to accept responsibility for the results of or any damage caused during operation.

As with all textiles, Luxaflex® fabrics are subject to some variations. Slight wrinkling, puckering or bowing is inherent in textile products and should be considered normal, acceptable quality. Precautions should be taken to reduce exposure to harsh environmental elements, such as salt air. Continuous exposure through open windows and doors will accelerate the fabric deterioration. Additionally, there will be slight differences in pattern alignment from the fabric on the rails to the fabric of the shade, which do not detract from the product's appeal. Variations in colour and/or pattern irregularities are unique characteristics that contribute to the classic beauty of a shade.

© Copyright 2021 Hunter Douglas Limited [ABN 98 009 675 709].
® Registered Trade Marks of Hunter Douglas Limited. 18.021.047 10/2021

luxaflex.com.au



LumiShade® Window Coverings



Operation

Chain and Cord operation

To open or close the fabric vanes, pull the chain until the vanes are tilted to the desired position. To traverse the blind, pull the cord until all vanes are stacked together in a desired position.



Traversing Wand operation

To open or close the fabric vanes, turn the wand until the vanes are tilted to the desired position. To traverse the blind, pull the wand until all vanes are stacked together in a desired position.



Motorised

For information regarding operation and programming of the LumiShade Motorised Window Coverings, refer to the Remote Control Guide.



Care and Cleaning

Routine maintenance

Dusting

Surface dust can be easily removed using a clean soft brush or feather duster.

Spot cleaning


To remove dirt and grime, simply wipe the fabric vanes with a sponge soaked in lukewarm water. If marks are still visible, add a little mild detergent and gently dry with a clean cloth.

Note: There can be significant variations between fabrics used with LumiShade Window Coverings, therefore, we recommend that you spot clean a small area as a test first.

Hand wash

LumiShade fabric can be lightly hand washed and dried, and can also be ironed with a cool iron or steamed to remove creases.

To remove fabric, gently unhook the fabric vane by lifting up and out of the hook.



CAUTION

Do not use harsh cloths, harsh abrasives, chlorine or ammonia based chemicals or cleaners on any surfaces as they may affect the surface appearance and durability.