

Roller Blinds

The information and advice included in this brochure has been prepared with care. However, we are unable to accept responsibility for the results of or any damage caused during operation.

As with all textiles, Luxaflex® fabrics are subject to some variations. Slight wrinkling, puckering or bowing is inherent in textile products and should be considered normal, acceptable quality. Precautions should be taken to reduce exposure to harsh environmental elements, such as salt air. Continuous exposure to the elements will accelerate the fabric deterioration. Additionally, there will be slight differences in pattern alignment from the fabric on the rails to the fabric of the blind, which do not detract from the product's appeal. Variations in colour and/or pattern irregularities are unique characteristics that contribute to the classic beauty of a blind.

Qmotion® is a registered trademark of Qmotion Incorporated. Somfy is a registered trademark of Somfy SAS. © Copyright 2023 Hunter Douglas [ABN 98 009 675 709]. © Registered Trade Marks of Hunter Douglas. 09/2023

luxaflex.com.au



Welcome to the Luxaflex lifestyle

Thank you for purchasing Luxaflex® Roller Blinds. With proper operation and care your new blinds will provide years of beauty and performance. Please review this instruction booklet thoroughly for operation and care information.

Operation

Standard chain operation

To lower the blind:

Pull the back of the cord loop to lower the blind.
Pull until the blind is at the desired height.

To raise the blind:

Pull the front of the cord loop to raise the blind. Pull until the blind is at the desired height.



LiteRise operation

Simply push up to raise the blind and pull down to lower the blind.



Qmotion® manual operation

- Pull down on bottom bar approximately 50mm. The blind will roll up to full open position.
- Pull down on bottom bar more than 50mm. The blind will stay at new lower position.
- Pull down on bottom bar 10mm to 20mm. The blind will roll up to the next intermediate position.



Motorised operation

For motorisation information, please refer to the SOMFY®, Motolux or PowerView® product brochure that is supplied with your blinds.



Care and cleaning

Roller Blinds are made from dust-resistant materials which repel dirt and dust. Periodic cleaning is recommended to help keep the blinds looking like new.

Routine maintenance

Dusting

Regular light dusting with a feather duster is all the cleaning needed in most circumstances.

Vacuuming

Use a hand-held vacuum with low suction for more thorough dust removal.

Spot cleaning

1. Prepare a solution of warm water and a mild detergent.
2. Dampen a clean cloth in the solution and wring it out.
3. Dab the spot with the dampened cloth until it is removed. Do not rub the fabric.
4. Allow the blind to dry in the completely lowered position.

